


Detrended Fluctuation Analysis

Introduction:

- Used to determine the self-affinity of a signal
- Self-affinity - property of fractal type time-series. It describes the way in which a smaller segment of a fractal structure is similar to the whole structure.
- Used mostly in time-series analysis
- Can also be applied in cases where statistical functions such mean and variance are non-stationary (i.e., they change with time).
- Related to measures based on spectral techniques like auto-correlations and fourier transforms.



1/F Structure (aka scale-free network or fractal):


- Before beginning Detrending Fluctuation Analysis (DFA), it is important to understand the $1/f$ concept.
 - ' $1/f$ ' refers to the structure of the power spectrum of the brain dynamics (and other physiological functions too).
 - $1/f$ is a kind of pink noise.
 - As power increases, the frequency decreases and vice-versa.
 - Sometimes, the mean of the data is not an accurate measure of the data.
 - There may be a large number of small-sized entities or vice-versa that impact the mean of the data.
- 

1/F Structure (contd.):

- Size of the entities of the data is related to their frequency of occurrence. This is a **scale-free network**.
- Most biological signals possess this $1/f$ noise.
- It poses a problem when we are trying to do time-series analysis.
- It does not mean that the $1/f$ noise is always bad for analysis.
- But, in order to observe the brain's response to certain external stimuli, we can remove the $1/f$ noise from the data to focus on fast time-scale dynamics.



Steps to perform DFA on signals:


1. Convert to mean-centered cumulative sum, i.e., subtract each value from the overall mean and take the cumulative sum of the entire set of obtained values.
 2. Define log-spaced scales.
 3. Choose a scale, split the signal into epochs based on the chosen scale, detrend it, and compute its individual RMS values.
 4. Repeat step 3 for all the other scales, and find overall average of each scale's RMS.
 5. Compute linear fit between log-scales and log-RMS.
- 

Precursor step:

In electrophysiology, it is better to perform DFA on the power spectrum of the signal or on its amplitude spectrum and not on the original time-domain signal. So, we can first compute its amplitude time-series using wavelet convolution (or any other method), and then proceed with DFA.



Points to remember:


1. Slope of the previously mentioned final linear-fit graph gives us the Hurst Exponent.
 2. Systems that have a long-range memory, show strong positive auto-correlations in time and have a Hurst exponent (DFA value) generally between 0.5 and 1.
 3. Hurst exponent is indicative of a system in critical state.
 4. Since DFA is something that analyses fluctuations over slower time periods like minutes/hours/decades, it cannot be applied to data that is only a few seconds long. Has to be long data.
 5. No. of RMS values corresponds to no. of scales.
- 

Points to remember: (contd.)

6. HURST EXPONENT (H)

H~0.5 - Brownian time series: Indicates high degree of randomness, negligible correlation between observations and future values, predictability of such signals is very less.

0<H<0.5 - Anti-persistent time series: Mean-reverting series, an increase will most likely be followed by a decrease or vice-versa (i.e., values will tend to revert to a mean). This means that future values have a tendency to return to a long-term mean.




Points to remember: (contd.)

0.5<H<1 - Persistent time series: In a persistent time series an increase in values will most likely be followed by an increase in the short term and a decrease in values will most likely be followed by another decrease in the short term. A Hurst exponent value between 0.5 and 1.0 indicates persistent behavior; the larger the H value the stronger the trend.


If $H > 1$, it means that DFA is not an appropriate analysis technique for that time-series data.




Signal 1: White noise




Signal 2: Real data




Noise s/g



Main s/g



Comparison of Hurst exponent



Hurst exponent:

Command Window

Hurst exponent of signal:

-0.0716

0.9145

Hurst exponent of noise:

-0.5957

0.4985

ne

REFERENCES:

<https://www.youtube.com/watch?v=-RmxLZF8adI>

https://en.wikipedia.org/wiki/Detrended_fluctuation_analysis

<https://www.frontiersin.org/articles/10.3389/fphys.2012.00450/full>

<https://pubsonline.informs.org/doi/10.1287/LYTX.2012.04.05/full/>

